


SANYO

INSTRUCTION MANUAL

MCD-S665F



**CD Portable FM Stereo/AM
Cassette Recorder**



CAUTION

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED IN THE OPERATION INSTRUCTIONS MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

THE COMPACT DISC PLAYER SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT PROPERLY QUALIFIED PERSONNEL.



CAUTION - INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.

ADVARSEL - USYNLIG LASER STRÅLNING VED ÅBNING. NÅR SIKKERHEDSÅBRYDERE ER UDE AF FUNKTION, UNDGÅ UDSÆTTELSE FOR STRÅLING.

VARNING - OSYNLIG LASER STRÅLNING NÅR DENNA DEL ÄR ÖPPNAD OCH SPARR ÄR URKOPPLAD. STRÅLEN ÄR FARLIG.

VORSICHT - UNSICHTBARE LASERSTRAHLUNG TRITT AUS, WENN DECKEL GEOFFNET UND WENN SICHERHEITSVERRIEGELUNG ÜBERBRÜCKT IST. NICHT, DEM STRAHL AUSSETZEN.

VARO ! - Avattaessa ja suojalukitus ohitettaessa olet alttina näkymättömälle lasersäteilylle. Älä katso säteeseen.




- The rating label is located on the bottom of the unit.

FOR SAFE AND EFFICIENT OPERATION


- The apparatus shall not be exposed to dripping or splashing.
- Do not damage the mains lead.
- When not in use, disconnect the mains lead from the outlet. Grasp the plug, not the cord, when disconnecting the unit.
If water should enter the unit, electrical shock or a malfunction may result.
Use in an area where there is low humidity and little dust.
- Do not disassemble or alter the unit in any way.
- Do not use the unit in areas where extremes in temperature occur (below 5°C or exceeding 35°C), or where it may be exposed to direct sunlight.
- Because of the CD player's extremely low noise and wide dynamic range, there is a tendency to turn the volume on the amplifier higher than necessary. Doing so may produce an excessively high output from the amplifier which can cause damage to your speakers. Please be careful in this regard.
- Sudden changes in the surrounding temperature can cause dew to form on the optical pickup lens inside the unit. Under this condition the unit may be unable to operate properly. If this should occur, remove the disc and allow the player to adjust to the surrounding temperature.

Do not install this equipment in a confined space, such as a book case or built in cabinet.


SPEAKER SYSTEM CONNECTIONS




To detach the speaker enclosures



To attach the speaker enclosures




POWER SUPPLY



Battery power operation

Install batteries.
Observe + and - signs.



CAUTION:

WHEN INSTALLING THE BATTERIES

To prevent leakage from the batteries, which is corrosive and can cause personal injury and damage to the unit, observe the following precautions:

1. The batteries must be installed correctly. Match the polarities (+ and - signs) on the batteries, to the polarities shown on the back of the unit.
2. Do not mix new batteries with old or used batteries.
3. Only use batteries of the same type and brand.
4. If the unit will not be used for an extended period of time, remove the batteries and store them in a cool place.
5. Carefully follow the battery manufacturer's instructions for proper use and disposal.
6. **DO NOT ALLOW YOUNG CHILDREN TO HANDLE BATTERIES.**


IMPORTANT NOTE:

When the batteries have become discharged, they must be disposed of in a safe manner which complies with all applicable laws.

AC power operation

Take out the cord and connect it.

AC INPUT





AC 230 ~ 240V,
50Hz

NOTES:

- When the AC mains lead is connected to the unit, the installed batteries will be automatically disconnected.
- The FUNCTION switch is mounted on the secondary side. The unit is not disconnected from AC power, even switched off.

GENERAL OPERATION


To control the sound



Bass expander switch (BASSXPANDER)

BOOST: (Button In) - Increases the bass output level.

NORMAL: (Button Out) - For normal bass output level.




Using headphones




COMPACT DISC OPERATION



CD PLAY




① TO CD.



② Push down.





Label facing up





Push down.

③ Press PLAY/PAUSE.




The PLAY indicator will light.

④ To control the sound.



Press STOP.



TO TAPE.

CD DISPLAY



- PLAY
- REPEAT
- MEMORY

The CD DISPLAY will show the total number of tracks on the disc as shown below.

TRACKS	CD DISPLAY
1 - 19	1 - 19
More than 19	"0" Flashes

Table

NOTES:

- *If a disc is loaded upside down, or if no disc is loaded, the CD player will not operate.*
- *Opening the CD compartment lid while a CD is playing could scratch the disc. Always press the STOP button and wait for the disc to stop rotating before opening the CD compartment lid.*

Compact discs


- Both 8 cm and 12 cm discs can be played in this unit.
NOTE: Place only one disc at a time in the CD compartment.
- Only discs bearing the logo as shown can be played in this unit.



- Always place the compact disc in the CD compartment with the label facing up. Compact discs can be played on only one side.
- Fingerprints and dust should be carefully wiped off the disc's signal surface (opposite the label side) with a soft cloth. Gently wipe in a straight motion from the inside to the outside of the disc.
- Discs should be returned to their cases after use to avoid serious scratches which could cause the player to skip.
- Do not expose a disc to direct sunlight, high humidity, or high temperatures for extended periods of time to prevent warping the disc.
- Do not apply paper or write anything on either side of the compact disc. Sharp writing instruments, or the inks used in some felt-tip pens, may damage the surfaces of the disc.
- Do not use cleaners or antistatic sprays on discs, such as those used for phonograph records.

IMPORTANT NOTE

If an abnormal display indication, or an operating problem occurs, disconnect the AC mains lead. Remove the D batteries (see page 3). Wait at least 5 seconds, then reconnect the AC mains lead. Reinstall the D batteries.



PAUSE MODE

1. Press the PLAY/PAUSE button during play. Play will temporarily stop, and the PLAY indicator will flash.
2. Press the PLAY/PAUSE button again to resume play. The PLAY indicator will remain ON.




Press and hold down during playback

TRACK SEARCH

1. In the play mode, press and hold down the **◀◀** or **▶▶** button to lower the volume level and quickly advance or return to any part of the disc. The CD DISPLAY will flash.
2. Release the **◀◀** or **▶▶** button to return the volume to normal level and resume play.

NOTE:

*If the **◀◀** or **▶▶** button is pressed during the PAUSE mode, no sound will be heard, and the PAUSE mode will continue when the button is released.*



Press and release repeatedly

TRACK SKIP

1. Press and release the **◀◀** or **▶▶** button repeatedly during play to quickly locate the beginning of a track.
2. The CD DISPLAY will show the number of the selected track. Play will continue from the beginning of the new track.


NOTE:

*If the **◀◀** or **▶▶** button is pressed while the unit is in the PAUSE mode, the unit will remain in the PAUSE mode when the button is released.*


PROGRAMMED PLAY

With programmed play, up to 16 tracks on a disc can be memorized and played in any order.



TO PROGRAM



① Press STOP.




② Press ◀◀ or ▶▶.



- The selected track number flashes.

③ Press MEMORY.



- The MEMORY indicator will light on the unit.

④ Repeat 2 and 3 to memorize additional tracks.

Checking the program


Press MEMORY.



To view the memorized track numbers, in the order they were entered.

TO BEGIN PROGRAM PLAY

⑤ Press PLAY/PAUSE.




Programmed play will begin.

- To cancel programmed play, press STOP twice.

The MEMORY indicator will go off.

REPEAT PLAY



REPEAT

Press REPEAT before or during play (or programmed play).



To cancel repeat play

Press REPEAT again.



- The REPEAT indicator will go off.

CD DISPLAY




○ PLAY

○  REPEAT


○ MEMORY

- The REPEAT indicator will light on the unit.


RADIO OPERATION





① To RADIO.





② To AM or FM.



③ Tune in a station.





④ To control the sound.



TO IMPROVE RECEPTION


FM - Extend and change position.

AM - Rotate unit.




CASSETTE TAPE OPERATION


PLAYBACK




① To TAPE.



② Press STOP/EJECT. Insert cassette.




③ Press PLAY.



Press to temporarily stop the tape during playback or recording. Press it again to continue.


To quickly wind the tape forward



To quickly wind the tape backward


Full automatic stop

This unit has a full-release stop system to protect the tape and prevent pinch roller damage. When the end of the tape is reached in Playback, Recording, Fast forward or Rewind, the tape mechanism will automatically stop.




Press STOP/EJECT once to stop the tape. Press again to remove cassette.

④ To control the sound.





RECORDING (RADIO)




① Press STOP/EJECT. Insert cassette.



■ STOP
▲ EJECT



② To RADIO.




To AM or FM.
Tune in a station.



③ Press REC.

● REC ▶ PLAY



Automatic Level Control (ALC) recording


The ALC circuit adjusts the recording input level automatically. No adjustments are required.

Safeguards against accidental erasure

To protect side A, break out tab (1). To protect side B, break out tab (2).



NOTE:

A cassette with the erase guard tabs removed cannot be erased or used for recording and the REC button cannot be depressed. To record or erase a protected cassette, cover the tab openings with adhesive tape (3).




BEAT CANCEL switch

When recording a radio program, an irritating "whistling" sound may sometimes be heard. If this occurs, select position 1, 2 or 3. Leave the switch in the position that gives the best results.




Back side of the unit

■ STOP
▲ EJECT





Press STOP/EJECT once to stop the tape.
Press again to remove cassette.

RECORDING (CD)





① Press STOP/EJECT. Insert cassette.

■ STOP
▲ EJECT




② To CD.



Label facing up

③ Press REC.



Synchronous recording (CD-to-TAPE SYNCHRO DUBBING)

This recording system starts disc play and cassette recording at the same time.

When the REC button is pressed, recording will start at the beginning of track number 1 of the disc.

If a program has been entered, recording will start from the beginning of the first programmed track.

MAINTENANCE

Cleaning the unit


Clean the outside of the unit with a clean soft cloth, moistened with lukewarm water. Do not use solvents such as benzene or thinner. These will permanently damage the units finish.

Cleaning the tape heads


When dust or reddish-brown oxide builds up on the tape deck heads, pinch roller and capstan, the following problems may result:

Poor sound quality during playback
Distorted, poor quality recordings
Erratic tape speed during recording or playback.

1. Press the STOP/EJECT button to open the cassette compartment lid.




2. Moisten a cotton swab (1) with Isopropyl alcohol or special head cleaning fluid. Gently rub the face of each head (4,5) with alcohol. Also clean the capstan (2) and pinch roller (3).



Cleaning the CD player lens

The lens should never be touched.

If dust is on the lens, blow it off using a camera lens blower. (Please consult your dealer.)



If trouble occurs...

To avoid the hazard of electric shock and damage to the unit, have the unit bench tested by an authorized SANYO service station. Do not remove the unit from its cabinet to attempt repairs yourself.

SPECIFICATIONS

(CASSETTE SECTION)

Recording system: AC bias 4-track stereo
Erasing system: Magnet Erase
Tape speed: 4.75cm/sec.
Fast forward and rewind time:
110sec.(C-60 tape)
Frequency response: 80 ~ 12,000 Hz
(Normal tape)

(CD SECTION)

Channels: 2 channels
S/N ratio: 70dB
Wow & Flutter: undetectable
Sampling frequency: 44.1kHz
Quantization: 16 bits linear/ch
Pick up light source: Semi-conductor laser
Pick up wave length: 790nm
Laser output: Continuous wave max.
0.6 mW

(RADIO SECTION)

Tuning ranges: AM: 525 ~ 1,710 kHz
FM: 88 ~ 108MHz
Aerials: Built-in ferrite bar and
telescopic aerials

(GENERAL)

Output power: 4.0 W x 2 (DC max.)
Speaker: 12 cm x 2, 4 ohms
PIEZO x 2
Terminal impedance: PHONES: 8 ~ 32 ohms
Power source: AC: 230 ~ 240 V, 50 Hz
DC: 12 V (8"D" size bat-
teries)
Dimensions: 541 x 274 x 215 mm
(W x H x D)
Weight (approx.): 6.0 kg including batte-
ries

Specifications subject change without notice.

SANYO