


INSTRUCTION MANUAL

CLT-538X

CORDLESS TELEPHONE



Please read these instructions completely before use.
If you have a problem with your cordless telephone, please see "TROUBLESHOOTING" on page 15 and "COMMON PROBLEM - QUICK CHECK GUIDE" on page 16 before calling for service.

CAUTION
THIS PRODUCT IS INTENDED FOR USE IN NEW ZEALAND ONLY.
SALE OR USE IN OTHER COUNTRIES MAY VIOLATE LOCAL LAWS.

IMPORTANT!

HANDSET BATTERY PACK

Charge the handset battery pack for a full 12 hours before using your cordless phone for the first time. (See pages 4 - 5.)

RINGER SWITCH

If the RINGER switch on the base station is set to the off position, no ring is heard when an incoming call is received. (See pages 8.)

GENERAL WARNING

The grant of a Telepermit for any item of terminal equipment indicates that only Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects, with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

IMPORTANT NOTICES

1. This equipment may not provide for the effective hand-over of a call to another device connected to the same line.
2. Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependant on local power, is available for emergency use.
3. This telephone does not include any date function and therefore Year 2000 compliance is not applicable.
4. Pulse dialling may not be used on this telephone.
5. The "flash time" setting of this telephone must be 600ms.

CONGRATULATIONS	2
UNPACKING	3
TIPS FOR BEST PERFORMANCE	3
INITIAL SETUP	
Installing the handset battery and initial charging	4
AC connection	4
Charging the handset	5
Phone line connection	5
Security code	6
NAMES OF CONTROLS	
Handset	7
Base station	7 - 8
BASIC OPERATION	
Before using the phone	8
Ringer volume setting	8
10-channel access/auto scan	8
Placing a call	9
Answering a call	10
ADVANCED FEATURES	
Speed dial (Handset only)	11
Redial	12
Flash button	12
Intercom	12
Room Monitoring	13
Transferring a call	13
MAINTENANCE	
Wall mounting	14
Rechargeable handset battery	14
MALFUNCTIONS	15
TROUBLESHOOTING	15
COMMON PROBLEM - QUICK CHECK GUIDE	16

CONGRATULATIONS

Your Sanyo **SUPER-COMPANDER** cordless telephone is a fine-quality home communications product. It is carefully designed and produced by a world leader of consumer and industrial electronics equipment. With proper maintenance and care, it will provide you with years of enjoyment and convenience.

The CLT-538X has many unique advanced features including:

Hands-Free Speakerphone on Base and dual keypad

Hands-Free speakerphone is included on base station. With a dialing keypad on both cordless handset and base station, the CLT-538X is like two telephones, and serves you as an intercom or 2-way pager.

SUPER-COMPANDER Noise Reduction

This fourth generation of Sanyo's original noise reduction technology now filters out more background noise.

10-channel auto scan

Your new telephone uses one of 10 channels that are now available for cordless telephones. It automatically selects a clear channel every time you receive or place a call on the handset. Should you wish to switch channels during a call, the handset provides a **CHANNEL** button.

Extended operating range

Illuminated keypad on both handset and base station

14-day standby

Notice:

This cordless telephone uses radio communication between the handset and the base station and may not ensure privacy of communication. Other devices, including other cordless telephones, may interfere with the operation of this cordless telephone or cause noise during operation. Cordless telephones must not cause interference to any licensed radio service.


UNPACKING

Check to make sure you have all the items that come with the system.


Handset



Base Station




AC Adaptor



Telephone Cord




Speed Dial
Directory Sheet



Model No. AD-B135
INPUT: AC 230V-240V, 50Hz
OUTPUT: DC 9V, 250mA
Polarity: Center Negative



Wall-Mount Bracket



Battery Pack
SANYO 3N-270AA




CAUTIONS:

- If you operate this product near water (bathtub, swimming pool, kitchen), take care to avoid contact between the water and the handset.
- Never spill liquid of any kind on the handset. This may cause a malfunction.
- Do not operate this product with dirty hands or allow the handset to be exposed to direct sunlight for extended periods. This can cause blurring, discoloration and fading of the lettering on the handset keypad. Discoloration or fading will have no effect on the telephone performance.


INITIAL SETUP

INSTALLING THE HANDSET BATTERY AND INITIAL CHARGING


1. Remove the battery compartment lid.




2. Plug the battery cord into the connector inside the compartment.



3. Place the battery in the compartment.



4. Replace the lid.



IMPORTANT: Charge the handset for a full 12 hours before using the cordless phone for the first time. Never attempt to use the cordless phone before this initial battery charge. See next page.


TIPS FOR BEST PERFORMANCE

BASE STATION LOCATION

For maximum operating range, extend the base station antenna to full length. In most cases, the best location for the base station is at the highest point in the house. Avoid places near electrical appliances and metal structures such as a refrigerator and filing cabinets that can reduce operating range and performance.

Away from electrical appliances such as a TV, radio, or personal computer.

In a HIGH and CENTRAL location with no obstructions.



Do not place the base station on top of or near a TV or VCR as this may interfere the performance of these appliances.


Replacement battery number:

SANYO 3N-270AA GP30AAK3BML

Use of other brands or types of batteries may cause serious damage or equipment malfunctions.

AC CONNECTION


1. Insert the small plug of the AC adaptor cord into the DC 9V AC ADAPTOR jack on the back of the base station.
2. Secure the AC adaptor cord under the hook located below the jack, as shown.
3. Plug the AC adaptor into an AC wall outlet



NOTE:
USE ONLY SANYO AC ADAPTOR MODEL NO. AD-B135
(APPROVAL NO. 14676)


CHARGING THE HANDSET

1. Place the handset on the base station for 12 hours. The **CHARGE/IN USE** indicator lights.
 - * The base station must be connected to AC power. (see page 4.)



2. Remove the handset from the base station.

From then on, recharge the handset for continuous 12 hours when the **TALK/BATT.LOW** indicator flashes at a few seconds intervals. (In addition, a beep sounds at the same intervals during phone use.)



Standby time


When the handset battery is fully charged, your Sanyo cordless phone offers up to **14 days of continuous standby time** or up to **10 hours of continuous talk time**. (Listed standby time is measured under a situation in which handset is kept in standby mode only—no phone calls are made or received). Under normal usage conditions, recharging is required more often.

CAUTION: Repeated recharging for shorter periods may reduce battery capacity.

PHONE LINE CONNECTION

Note:

Please make sure that the handset battery is fully charged before connecting the phone line cable.



WARNINGS

- This cordless telephone may, on some longer lines, have difficulty handing over to another device connected to the same line.
- Immediately disconnect the equipment should it become physically damaged, and arrange for its disposal or repair.
- The operation of this equipment on the same line as telephones or other equipment with audible warning devices or automatic ring detectors will give rise to bell tinkle or noise and may cause false tripping of the ring detector. Should such problems occur, the user is not to contact Telecom Faults Service.

CAUTION


This telephone is for use with a "tone dialing system" only. If you have a pulse dialing lines, you can't use this cordless telephone.

SECURITY CODE

This cordless telephone has a digital security system with 10,000,000 possible codes. This system helps prevent the unauthorized use of your telephone line by another cordless telephone.

How to reset your security code

1. Place the handset in the base station cradle.




2. Within 8 seconds, press **INTERCOM•PAGE/FIND** on the base station. The **CHARGE/IN USE** indicator flashes, and then lights steadily. The security code is now set.


NOTES:

- To change your security code at any time, simply repeat the above steps. A new security code is automatically set each time.
- If you experience difficulty in resetting security code, first disconnect the AC adaptor from the unit, reconnect it, and then try again.


HANDSET



BASE STATION




BASE STATION



BASIC OPERATION

BEFORE USING THE PHONE

1. Take the handset to the location you want to use it.
2. Press the **TALK/VOL** button. Verify that you get a dial tone and the **TALK/BATT.LOW** indicator lights. Your handset is ready to use.
3. Place a call or press **END** to hang up.



NOTE:

The base station **CHARGE/IN USE** indicator will flash when **TALK/VOL** button is pressed.

RINGER VOLUME SETTING

You can set ringer volume low or high in standby mode. Every time you press and hold the **RINGER VOL.** button for at least one second, ringer volume changes between low and high alternately. When reset, the handset rings at the selected volume level.



10-CHANNEL ACCESS/AUTO SCAN

Every time you answer or place a call using the handset, this cordless telephone automatically selects a clear channel from 10 channels available to transmit signals between the base station and handset. If you notice interference during a call, simply press the **CHANNEL** button on the handset to access a clear channel.



PLACING A CALL

USING THE HANDSET


1. Press **TALK/VOL**.
(Or lift the handset from the base station and then press **TALK/VOL**.)
The **TALK/BATT.LOW** indicator lights. The dialing buttons also light for approximately 10 seconds.



2. Dial the number.



3. Press **END** to hang up.



To adjust the volume


Press **TALK/VOL** once during a call.
The volume level changes in two steps each time **TALK/VOL** is pressed: normal or loud




USING THE BASE STATION

You can make a phone call without the handset.


1. Press **SPEAKER** to get a dial tone.
The **SPEAKER** indicator lights and **CHARGE/IN USE** indicator flashes.
The dialing buttons also light for approximately 10 seconds.



2. Dial the number.



When the call is answered, speak into the microphone



3. Press **SPEAKER** to end the call.



ANSWERING A CALL

ANSWERING WITH THE HANDSET

When a call comes in, the dialing buttons and the **TALK/BATT.LOW** and **CHARGE/IN USE** indicators flash.



1. Press **TALK/VOL**.
(Or lift the handset from the base station.)



ANY KEY ANSWER

You can also press any key on the handset except the **END** key to answer the call.

2. Press **END** to hang up.



NOTES:


- The cordless handset may ring slightly after the base station.
- If the handset is too far away from the base station, pressing **END** may not hang up a call. If this happens, come closer to the base station and then press **END**.

ANSWERING WITH THE BASE STATION

You can answer an incoming call using the base station speakerphone without picking up the handset.

When a call comes in, the dialing buttons and the **CHARGE/IN USE** indicator flashes.

1. Press **SPEAKER** to answer a call.
The **SPEAKER** indicator lights and **CHARGE/IN USE** indicator flashes



Use the **VOLUME** control on the side to adjust the speaker volume.



2. Press **SPEAKER** again to end the call.




NOTE: If the **RINGER** switch is set to the **OFF** position, the base station will not ring.

SPEED DIAL (Handset only)


The handset can store up to 10 phone numbers in its memory. You can dial a stored number simply by pressing the **MEMORY** button and the assigned 1-digit memory location number.

To store numbers in memory

1. Press and hold the **MEMORY** button for at least one second. The **TALK/BATT.LOW** indicator flashes. The dialing buttons light for approximately 10 seconds.



2. Dial the phone number you want to store using the handset keypad. If you make an error while storing a number, press **END** to cancel the operation. To resume, begin with step 1.
 - Up to 16 digits can be stored. (A pause counts as one digit.)



3. Press the **MEMORY** button.



4. Press a number button (0-9) to assign a memory location number to the phone number.



A beep sounds, and the **TALK/BATT.LOW** indicator goes off. The phone number is now stored. The lights of the dialing buttons also go off.

5. Write the stored phone number on the speed dial directory sheet (included).
6. Repeat steps 1 - 5 to store other numbers or to change previously stored numbers.

To insert a pause:

Stored phone numbers can include a 2-second pauses between two digits (after 1 to get an outside line in a PBX system, for example). Press the **REDIAL/P** button after the first digit.

To dial a number stored in the memory


1. Press **TALK/VOL**.



2. Press the **MEMORY** button.



3. Enter the location number (0-9) using the handset keypad.



To clear a specific stored number

1. Press and hold the **MEMORY** button for at least one second.
2. Press the **MEMORY** button again.
3. Enter the assigned speed dial number. The number stored in this location has been erased.

Speed dialing can be performed using the handset keypad only.

The speed dial memory may be erased if the handset battery is replaced or exhausted.

REDIAL

You can automatically redial the last number called using the **REDIAL/P** button on the handset or base station. A number of up to 32 digits can be redialed.

- The **REDIAL/P** button on the handset redials the last number called using the handset keypad.



- The **REDIAL/P** button on the base station redials the last number called using the base station keypad.



NOTE:

To redial after hearing a busy signal, press **END**, then **TALK/VOL**, then the **REDIAL/P** button.

FLASH BUTTON

You can use the **FLASH** button to answer the second party when you subscribe to **CALL WAITING** service offered by your phone company and **PBX** system.

If you subscribe to CALL WAITING...

1. If a call comes in when you are already on the phone, a beep sounds.
2. Press **FLASH**. The first call is placed on hold, and you can talk to the second caller.



3. Press **FLASH** again. The second caller is placed on hold, and you can talk to the first caller.



NOTE: The **FLASH** button may also be used to get a new dial tone without pressing the **END** button or replacing the handset in the base station cradle. However, if your telephone line has special service features (like **CALL WAITING**), the **FLASH** button may not operate in this way.

INTERCOM


The intercom feature allows wireless communications between the base and handset users. The paging feature can also be used as a handset locator.

From Handset to Base Station (Auto Intercom)

1. Handset: Press the **INTERCOM** button to page the base station. Base station automatically switches to intercom mode. The **CHARGE/IN USE** indicator flashes and **SPEAKER** indicator lights.



2. Handset/Base station: Begin intercom conversation.
3. Handset: Press **END** to turn off the intercom.



From Base Station to Handset


1. Base station: Press **INTERCOM-PAGE/FIND** to page the handset. The **CHARGE/IN USE** indicator flashes.

When the handset is paged by the base station, the **TALK/BATT.LOW** indicator flashes.



2. Handset: Press **TALK/VOL** (or any key except **END**) and begin intercom conversation. The **TALK/BATT.LOW** indicator lights.

3. To turn off the intercom, press **END** on the handset.



Room Monitoring


Using the intercom feature, the handset user can monitor the ambient sound of the room where the base station is located

1. Press the **INTERCOM** button to begin monitoring.



(To improve the clarity of the monitor sound, cover the handset microphone with your hand.)

2. Press **END** to end monitoring.



Handset Locator

If you misplace the handset, press **INTERCOM•PAGE/FIND** on the base station to make the handset beep.



TRANSFERRING A CALL

A call can be transferred between the handset and the base station.


From Handset to Base Station

1. Handset: Press the **INTERCOM** button to alert the base station. The **TALK/BATT.LOW** indicator flashes.



The call is put on hold.
Speak to the base station user.

2. Handset: Press **END**. The base station user can now talk to the caller using the speakerphone.




Handset: (If the base station does not answer, press **TALK/VOL** to talk to the caller again.)

From Base Station to Handset


1. Base station: Press **INTERCOM•PAGE/FIND** to alert the handset user. The call is put on hold. The **CHARGE/IN USE** and **SPEAKER** indicators flash.



2. Handset: Press **TALK/VOL** (or any key except **END**) to answer the base station.



3. Handset: Press **TALK/VOL** again to talk to the caller.




Base station: If the handset user does not answer, press **SPEAKER** to talk to the caller again.



WALL MOUNTING

To mount the base station on a wall

1. Insert the hooks of the wall-mount bracket in the holes (1) on the underside of the base station. Then push them in the direction of arrow (2) as shown.



2. Connect a short modular telephone cord (not supplied) to the wall plate.
3. Mount the base station on the wall phone plate and seat it securely.

RECHARGEABLE HANDSET BATTERY

Recharge handset in the base station cradle for a continuous 12 hours when the **TALK/BATT.LOW** indicator flashes. (See page 5)

Repeated recharging for shorter periods may reduce battery capacity.

Battery Refresh

If your battery seems to need recharging more often than usual, it may have lost part of its charging capacity because of premature recharging. To return the battery to its full capacity, try the battery refresh procedure.

- Discharge the battery by leaving the handset in talk mode until the **TALK/BATT.LOW** indicator flashes. (First, disconnect base station from phone line.)
- Charge the handset for 12 hours.
- Repeat this procedure once more.


If performance still doesn't improve, it's time to replace the battery.

REMEMBER: Reset security code after a battery refresh (page 6).


REMEMBER:
Your handset battery needs recharging when you hear a beep every few seconds during phone use. (The **TALK/BATT.LOW** indicator flashes at the same intervals.)

Cleaning the contact points

To ensure that the handset battery charges properly, clean the contact points on the handset and the base station once a month with a soft cloth.



Contact points



Contact points

Although it is unlikely that the base station will malfunction, if it does, disconnect it from the telephone line until proper repairs are completed.

The cordless telephone uses radio frequencies for transmission and reception, and is subject to certain operating conditions. The following conditions are normal and could affect the operation of your system.

1. NOISE

Electrical pulse noise is present in most homes at one time or another. This is most intense during electrical storms. Certain kinds of electrical equipment such as light dimmers, fluorescent bulbs, motors, fans, etc., also generate these noise pulses. Because radio frequency transmissions are susceptible to these pulses, on occasion you may hear them in your handset. Generally they are a minor annoyance and should not be interpreted as a defect in your system.

2. RANGE

Because radio frequencies are used, the location of the base station can affect the operation range. Try several locations in your home or business and pick the one that gives you the clearest signal to the handset. Turning around while holding the handset may help you find the best position.

3. INTERFERENCE

Electronic circuits activate a relay to connect the cordless telephone to your telephone line. These electronic circuits operate in the radio frequency spectrum. While several protection circuits are used to prevent unwanted signals, there may be periods when these unwanted signals enter the base station. You may hear clicks or hear the relay activate while you are not using the cordless handset. If this starts occurring frequently, it can be minimized or eliminated by lowering the height of your base station antenna, or relocating the base station. Check for interference before selecting your final base station location by plugging it in and monitoring it for clicks.

Two cordless systems should not be operated too close to each other because of interference. This interference can be reduced by lowering your base station antenna, thereby reducing its range.

TROUBLESHOOTING

Most cordless phone problems can be corrected quickly and easily — without service. If you experience difficulties, try the suggestions below before taking your phone in for service.

If the phone doesn't work at all

- Security code may have been canceled. To reset, see page 6.
- AC adaptor may not be plugged into wall outlet or base station.
- Telephone line may not be connected.
- Handset battery may be extremely low. If TALK/BATT.LOW indicator flashes in talk mode, recharge battery. (See page 14).
- Handset may be too far from base station. Move closer.

The operating range seems shorter

- Check the base station location for interfering objects. (See page 3.)
- Extend the base station antenna to full length.

Handset battery life or standby time seems shorter

- Handset battery may have been repeatedly recharged before being fully exhausted. Try Battery Refresh (See page 14).
- Battery may need replacing (See page 4.)

Incoming calls do not ring on handset

- Handset may be too far from base station. Move closer.
- More than one cordless phone is connected to the same line and they may be using a same channel. Change the channel of a phone by pressing the CHANNEL button.

Incoming calls do not ring on base station

- The RINGER switch may be set to OFF.

Reception is noisy (interference, hum or static)

- Switch to a clearer channel. (See page 8.)
- Base station may be too close to electrical equipment. Try another location.
- Handset may be too close to large metal object(s). Move to another location, or change direction while using handset.
- Lower base-station antenna to reduce interference range.

If phone still does not work

- Reset base station and handset as follows:
 1. Disconnect AC adaptor, and then reconnect AC adaptor to reset base station.
 2. Disconnect then reconnect the handset battery.
 3. Reset security code. (See page 6.)

"If you have a problem with your cordless telephone, try the following suggestions before calling for service"

NO.	SYMPTOM	CHECK	IF	SOLUTION
1.	NOISE	A. Is the antenna of the base station fully extended?	NO	Fully extend the antenna.
		B. Is there any electronic equipment nearby? (For eg: personal computer, FAX, etc)	YES	Move the base station and handset further away from them.
		C. Is there any object which obstructs radio frequencies between the base station and handset? (For eg: concrete, tile walls or metal object, etc)	YES	Try to move the base station to another location.
		D. Is another cordless phone nearby?	YES	Try to change the channel used by pressing the CHANNEL button on the handset.
		E. Fluorescent lamps or other electronic equipment may generate noise pulses.	YES	Move the base station and handset further away from them.
		F. Are you hearing beeps for battery alarm during phone conversation?	YES	The handset battery is low. Recharge it.
2.	CUT OFF	A. Is the TALK/BATT. LOW indicator lit?	YES	Recharge the handset battery.
		B. Is the telephone line cutting off during phone conversation?	YES	Make certain that the AC adaptor is firmly connected to both the base station and an AC wall outlet. Also make certain that the handset battery is firmly connected to the socket in the compartment.
		C. Is the phone interrupted during phone conversation?	YES	Check the above ITEM (B-E) of NOISE SYMPTOM, No. 1.
3.	NO CHARGE	A. Is the CHARGE/IN USE indication lit with the handset placed on the base station cradle?	NO	Clean the battery charging terminals on the handset and base station with a soft cloth.
		B. Does the TALK/BATT. LOW indicator not go off, even if the handset battery is recharged?	YES	Same as above. If the performance still does not improve, replace the handset battery.
4.	LOSS OF SECURITY CODE	A. Does a continuous beep sound in the handpiece?	YES	1. Place the handset in the cradle of the base station. 2. Press the INTERCOM*PAGE/FIND button on the base station (within 8 seconds). A beep sounds within 30 seconds. The security code is now set.