




# WALL MOUNTING INSTRUCTIONS

## ⚠ Safety Precautions:


- Thoroughly read this instruction before setup and follow the steps below precisely.
- The wall to be mounted should be nonmetal wall.
- Very carefully handle the unit during setup and consult authorized service personnel to ensure successful installation. We are not liable for any damage or injury caused by mishandling or improper installation.
- Be sure to place the unit on a stable and soft platform which is strong enough to support the unit.
- Do not uplift the speaker when moving the display. The illustrations shown below are for reference only.
- Design and specification are subject to change without notice.




Fix the Wall mounting holder on the wall with 4 pcs expansion bolts.  
If the wall is wooden structure, please use 8 pcs wood screws.



Fix the Wall mounting connector on the back cabinet of the unit with 4 pcs M4 screws.



As shows in fig.4, put the assembled unit close to the Wall Mounting Holder on the wall, then insert the 2 insertions into the relevant locating grooves and let the unit slowly slide along the locating groove to the end.



With a screw driver, turn the Locating buckle to the locating hole according to the arrow direction.