


OPERATING INSTRUCTIONS**INSTALLING BATTERIES**

Slide the battery lid to remove it. Install two "R03/AAA" batteries (not supplied) with the proper polarity (see diagram in the battery compartment), then close the lid.

Note:

Dispose of used batteries safely and in accordance with all applicable laws.

If the unit will not be used for a long time, remove the batteries.

SPECIFICATIONS

Tuning range:

FM: 87.5 - 108 MHz

AM: 526.5 - 1606.5KHz

Power output

80 mW

Power source:

DC 3V, 2 "R03/AAA" batteries

OPERATION

1. Set the Band selector to AM or FM.
2. Connect the earphone to the EAR socket if required.
3. Turn the TUNING control to tune in a desired station.
4. Adjust the VOLUME control as desired.

To improve reception

FM: Pull out the antenna and adjust its position.

AM: Rotate the unit.