


## Installing the SCART to VCR cable with the FOXTEL Digital Set Top Unit

### To connect the SCART to VCR cable to your VCR:

- 1) Connect the SCART plug to the VCR SCART connector on the rear of the Set Top Unit. To identify which of the two SCART connectors is the VCR SCART look at the back of the FOXTEL Digital Set Top Unit, the VCR SCART will be marked either VCR or with the  symbol.
- 2) Plug the cable with the yellow RCA connector marked "Video OUT" into the **Video/Line IN** connector on your VCR.
- 3) Plug the cable with the yellow RCA connector marked "Video IN" into the **Video/Line OUT** connector on your VCR.
- 4) Plug the cable with the red RCA connector marked "Audio Out – R" into the **Audio/Line IN R** input on your VCR.
- 5) Plug the cable with the red RCA connector marked "Audio IN – R" into the **Audio/Line OUT R** input on your VCR.
- 6) Plug the cable with the white RCA connector marked "Audio Out – L" into the **Audio/Line IN L** input on your VCR.
- 7) Plug the cable with the white RCA connector marked "Audio IN – L" into the **Audio/Line OUT L** input on your VCR.

### To connect the SCART to VCR cable to your Television:

- 1) Connect the SCART plug to the TV SCART connector on the rear of the Set Top Unit.
- 2) Plug the cable with the yellow RCA connector marked "Video OUT" into the Video IN connector on your Television.
- 3) Plug the cable with the red RCA connector marked "Audio Out – R" into the Audio IN – Right connector on your Television.
- 4) Plug the cable with the white RCA connector marked "Audio Out – L" into the Audio IN - Left connector on your Television.

*Note: The cable is labelled from the viewpoint of the SCART connector; thus, the connector marked "Video OUT" carries video out of the FOXTEL Digital Set Top Unit.*

In order to view VCR content on your television, press the AV button on your remote; the VCR signal will be automatically looped through the FOXTEL Set Top Unit. To view FOXTEL content press the FOXTEL button on your remote.

If you want to use the "loop-through" facility, your television must be connected to the TV-SCART connector on the FOXTEL Digital Set Top Unit while the loop-through device (eg VCR) must be connected to the VCR SCART connector on the FOXTEL Digital Set Top Unit. The Video Output from the Set Top Unit must be set to PAL. For further discussion on the loop-through feature refer to the Foxtel Digital Set Top Unit User Guide.



**FOXTEL** 

## Installing the SCART to VCR cable with the FOXTEL Digital Set Top Unit

### TROUBLESHOOTING:

Ensure that the correct connector is plugged into the proper input on your Television or VCR. The connections are as follows:

#### a) Television

SCART cable connector	Television connector
Video OUT (yellow)	Video IN
AUDIO OUT (red)	Audio IN – Right
AUDIO OUT (white)	Audio IN - Left

#### b) VCR

SCART cable connector	VCR connector
Video OUT (yellow)	Video/Line IN
Video IN (yellow)	Video/Line OUT
Audio OUT (red)	Audio/Line IN R
Audio IN (red)	Audio/Line OUT R
Audio OUT (white)	Audio/Line IN L
Audio IN (white)	Audio/Line OUT L

Ensure that you have selected the correct input on your Television or VCR.

If you require further technical assistance, please contact your retailer or the support hotline 1300669347 8:30-6:00PM (Eastern Standard Time).



**FOXTEL** 