




1) Select DVD mode from the Sources on R/C



2) In DVD mode, please press "DISPLAY" button on Remote Control
You will see the DVD menu



3) Then press the buttons "1, 3, 5, 7" on the RC with the same order
You will see an hidden menu as shown below.



4) You can adjust the settings from this menu with using the RC cursor buttons

- DIVX Support on/off (on your product, it have to be 'on')
- SPDIF Audio formats (on your product, it must be '1 RAW')
- Region Code (from 0 to 6) (on your product, it must be '4')

5) After finishing the adjustments, press the DISPLAY button again for exit