



# SANYO

## CORDLESS VACUUM CLEANER

### CORDLESS VACUUM CLEANER




### ASSEMBLING CHARGING PLUG TO WALL BRACKET



1. Position the charging plug at the bottom of the wall bracket as shown.
2. Push charging plug forward and insert into hole of wall bracket.
3. Use pliers to rotate the plug 90° to fix in place.

### TO WALL MOUNT



Your cordless vacuum is designed to hang vertically on the wall with the nozzle end pointing downward. Position the wall mount close to an electrical outlet.

1. Use a 1/4" drill bit for drilling holes for the plastic anchors.
2. Insert anchors and use screws to affix the wall mount bracket to the wall.
3. Slide vacuum downward onto wall bracket and plug into the electrical outlet.
4. The LED charging indicator will light up to indicate that the unit is charging. You may leave your vacuum on charge continuously so that it is always ready for use.

NOTE: Your cordless vacuum is supplied in a low charge condition.

Please ensure that the vacuum is charged for 10 - 12 hours prior to initial use.

### INSTRUCTIONS FOR USE

1. The On/Off switch on the handle will turn the unit on when pushed forward and automatically turn unit off when released.
2. To pick up dry debris, vacuum in any direction until area is clean.

A crevice tool is provided for clean-ups in hard to reach areas and can be stored in wall mount bracket.

### CLEANING UNIT

1. For best results, always start with a clean filter bag. Clean the bag after each use.
2. Hold vacuum with nozzle end pointing downward. Press release button and separate the container from the motor unit.
3. Empty the container. Remove filter from dust collector.
4. For heavily soiled filters, wash in soapy water using a soft brush if necessary. Let dry thoroughly before assembling.

### CAUTION

1. Never immerse the motor unit in water or any other liquid.
2. Do not clean any vacuum parts in a dishwasher.
3. Do not use any charger other than the one provided.
4. Never place fingers near the fan when operational.
5. Close supervision is recommended when being used by children.
6. Do not use to vacuum any type of liquids including flammable or corrosive liquids.
7. Do not use charger plug if it has been damaged in any way.
8. Never unplug the charger by pulling on the cord.
9. This product is for household use only.
10. Never operate unit without the filter being in place.

### ATTENTION

Please charge the unit fully before using

PC-148 / PC-149

OPERATION  
INSTRUCTIONS

# SANYO

Sanyo Australia Pty Ltd Inc in Victoria

## Personal Records

Model NO \_\_\_\_\_ Serial No \_\_\_\_\_ Retailers Name \_\_\_\_\_

Original Buying Date \_\_\_\_\_ Suburb/Town/City \_\_\_\_\_

## Sanyo

**Sydney**  
211 Walters Rd  
Arndell Pk  
NSW 2148  
Ph (02) 8825 2822

**Melbourne**  
370 Whitehorse Road,  
NUNAWADING VIC 3131  
Ph (03) 9875 4444

**Brisbane**  
Brisbane  
1/17 Mayneview St  
Milton 4064  
Ph (07) 3367 0799

**Adelaide**  
219 Gouger Street  
ADELAIDE SA 5000  
Ph (08) 8410 3277

**Perth**  
Unit 5/177 Bannister Rd  
Canning Vale 6155  
P.O. Box 129 Cloverdale  
Ph (08) 9456 1682

## Sanyo Regional Repairers

**Newcastle**  
Dadnj Electronics  
17 Arnott St  
Newcastle West 2302  
Ph (02) 4929 5197

**ACT**  
Santronics  
15 Kembla St  
Fyshwick 2609  
Ph (02) 6280 6422

**Wollongong**  
Electronic Services  
208 Corrimal St  
Wollongong 2500  
Ph (02)4227 3233

**Townsville**  
TV & Audio Service Ctre  
53 Thuringowa Dve  
Kinwan 4814  
Ph (02) 7773 4433

**For Further Sanyo repairers and Sanyo office automation dealers  
Please ask your closest Sanyo office**

You will keep your Sanyo warranty if you provide proof of original buying date when requesting service for your product bought in Australia.

### **OTHER RIGHTS:**

Your express and implied rights and remedies under the Trade Practices Act and other laws are different to your Sanyo warranty benefits.

### **SANYO WARRANTY:**

Except for the clauses below, Sanyo will repair (or at its option replace) any part of your Sanyo product which in its or its repairer's opinion needs repair or replacement because of manufacture or parts during the 2 years commencing from your products original buying date.

### **HOW TO CLAIM YOUR SANYO WARRANTY:**

- Please provide proof of original buying date when requesting Sanyo warranty service - for your product bought in Australia.
- Please install and use your product in accordance with instructions on your operating manual.

### **PLACE AND TIME OF SERVICE:**

Please take or send your product (at your cost and risk) to and from Sanyo or its repairer. If you send your product and / or leave it with or it is taken by Sanyo or its repairer you are wise to insure it for both the sending and return journey. Sanyo service hours are only Monday to Friday (excluding public holidays) 8.30 am to 4.30 pm

Services for which you may be asked to pay at the then current rates

Repairs needed because of

- Leaking batteries
- Accident, misuse, negligence or tampering with
- Use other than in accordance with instructions on your product or in your operating manual
- Lightning strikes
- Salt built up or rust or corrosion if you live near the ocean or in a high humidity area
- Repairs or attempted repairs by anyone other than Sanyo or its repairer
- Use of the product on voltage other than that specified for your product.
- Repairs to your product if bought at auction.