

# **SANYO**

SANYO Australia Pty Ltd

**CONSUMER ELECTRONICS DIVISION**

**TECHNICAL BULLETIN No. 59      DATE: 28/11/03**

## ***SUBJECT: DVD-7201 & DVAVD-8501 MULTI-ZONE PROCEDURE***

### **Method:**

- Step 1.** Press the "Open"\* button.
- Step 2.** Insert the Firmware Update CD-R into the Disc-Tray.
- Step 3.** Press the "Close"\* button. (Display on Player = "READING")
- Step 4.** Wait until the TV screen displays "to start updating : press PLAY key"
- Step 5.** Press the "PLAY" button.
- Step 5.** Wait until the set goes into "Stand By" (approx 30-40 seconds).  
(“STANDBY” Light turns ON)
- Step 6.** Press the "POWER" button and then the "Open" button. Remove the CD-R from the Disc-Tray. The firmware update is finished at this point.
- Step 7.** Switch the power OFF and ON at the power outlet.

### **Warning:**

If the above procedure is not followed exactly or there is a power interruption during the upgrade process, the player will be damaged! The repair of this damage will be costly and NOT covered by warranty!

\*Comment: The "Open" and "Close" buttons are the same button and marked as "Open/Close".