

# SANYO

SANYO Australia Pty Ltd

CONSUMER ELECTRONICS DIVISION

**TECHNICAL BULLETIN No. 83    DATE: 3/11/09**

**SUBJECT: LCD37XR9DA Hum at low volume**

**Fault:**

The TV emits a low hum when the "Light Sensor" is set to "On" in the "Picture" adjustment menu.

**Cause:**

Earth-loop from the Inverter PCB causing ripple on the Audio circuit supply.

**Remedy:**

- **Temporary fix:**  
Turn off the "Light Sensor" in the "Picture" adjustment menu. (Refer to page 21 of the instruction manual.)
- **Permanent fix:**  
Remove the earth lug from the Inverter PCB.

**Method:**

Remove the earth lug located under the right hand side middle screw hole of the Inverter PCB.

