About the PDF-format Instruction Manuals

The English, German, French, and Spanish instruction manuals for the Camera and the SANYO Software Pack are stored as PDF files in the SANYO Software Pack CD-ROM. To read the PDF files, you will need Adobe® Acrobat® Reader 3.0 or later. If one is not installed in your computer, install it from the SANYO Software Pack CD-ROM. An English version of Adobe® Acrobat® Reader 4.0 is provided on the SANYO Software Pack CD-ROM. If you need a version for a different language, you can download it from the web site given below.

http://www.adobe.com/prodindex/acrobat/readstep.html

The contents of the SANYO S	offware Pack CD-HOM:
[CD-ROM] —— [DOCS] —	[Acrobat]
• •	[English] — Camera_GB.pdf — [Deutsch] — Software_GB.pdf
	[Francais] [Espanol]
	[Espanol]

■ To install Acrobat Reader

For information on how to use Acrobat Reader, read the Help files of Acrobat Reader.

Installing to a Windows computer

- 1 Set the CD-ROM in the CD-ROM drive.
- 2 Double-click on the My Computer icon on the desktop.
- 3 Double-click the setup file located in the Acrobat folder in DOCS inside the CD-ROM.
 - When the installer window opens, follow the instructions given on the screen and complete the installation of Acrobat Reader.

Installing to a Macintosh computer

Double-click the installer icon located inside the Acrobat folder that is inside the DOCS folder on the CD-ROM.

 When the installer window opens, follow the instructions given on the screen and complete the installation of Acrobat Reader.