

Notice

- | | |
|---------------------------------------------------|--------------------------------------------|
| <input type="checkbox"/> CORRECTION | <input type="checkbox"/> PRODUCTION CHANGE |
| <input checked="" type="checkbox"/> SERVICE FLASH | <input type="checkbox"/> ADD INFORMATION |

FILE NO.

REVISION-5

Please add this notice to the Service Manual listed below.

Category : Multi-media Projector	Issued Date : January / 2008
Model : PLC-XF35NL PLC-XF35N PLC-XF35	Effective from : MY8-XF35NL00 MY8-XF35N00 Chassis No. MY8-XF3500
Destination : U.S.A.,Canada, Europe,Asia,Africa	REF. NO. : SM5110413

NOTE: Match the Chassis No. on the cabinet top with the Chassis No. in the Service Manual. **If the Chassis No. does not match the unit's**, additional Service Literature is required. Only the Difference Service Information is given in this manual. For detail Service Information, Refer to the Original Service Manual SM5110413-00, issued in November 2002, for Model PLC-XF35 / PLC-XF35N / PLC-XF35NL.

Service Flash :

Change of service parts-(LCD panels). Currently used **LCD panels were discontinued.**
(Effective for chassis No. MY8-XF3500 / XF35N / XF35NL.)

When currently used LCD panel is exchanged, it is necessary to exchange the newly 3 LCD panels(R,G,B). After replacing LCD panels and LCD/Prism assy, change the service adjustment data.

Note:

When ordering this LCD panel and LCD/Prism assy, give the following information to the Projector Division Service parts section. (Model No. and Serial No.)

FILE WITH ORIGINAL SERVICE MANUAL (SM5110413)

PRODUCT CODE

1 122 154 00 (MY8A)	1 122 155 00 (PY8A)
1 122 154 20 (MY8AA)	1 122 155 02 (PY8C)
1 122 154 30 (MY8AL)	

LCD/Prism assy exchange.

LCD panel / Prism Assy part No. 610 301 6504 (Currently used)



LCD panel / Prism Assy part No. 910 320 5084 (Newly added)

LCD panels exchange.

Currently used

Item No.	Parts No.
EL901B	645 054 2626 B-LCD panel
EL901G	645 054 2619 G-LCD panel
EL901R	645 054 2602 R-LCD panel

Newly added as sub

Item No.	Parts No.
EL901B	945 075 1630 B-LCD panel
EL901G	945 075 1623 G-LCD panel
EL901R	945 075 1616 R-LCD panel

Exchange simultaneously

When currently used LCD panel(R or G or B) is exchanged, it is necessary to exchange the newly 3 LCD panels(R+G+B) simultaneously.

When a currently LCD panel ordered, newly 3 LCD panel is supplied.

Adjust service mode data.

After replacing LCD panels and LCD/Prism assy, change the service data.

1. Enter the service mode.
2. Select the Group No.920, Item No.1 and change data value from 15 to 6

Group No.	920
Item No.	1
Data	15 ----> 6 (Factory default value =15)

(Sample & hold positioning setting)

3. Exit the service mode.

Note: Service mode is refer to "Service mode adjustment menu"