



**Sanyo Software Pack 6.7
For Digital Camera**

INSTRUCTION MANUAL

Please read these instructions carefully before using. Be sure to keep this manual for later reference.

ATTENTION

Regarding permission to use the CD-ROM

- This CD-ROM may not be reproduced without permission.
- When installing the software in this CD-ROM, permission is granted for its use only if the user agrees to the terms and conditions that are displayed at the start of installation.
- Regarding products by other manufacturers that are specified on this CD-ROM, and for service, please inquire of the respective manufacturer.
- It is strictly forbidden to copy this manual, whole or in part, without prior written permission.
- The contents of this manual are subject to change without prior notice.
- Sanyo Electric shall not be held responsible for any problems resulting from the use of this product.
- Sanyo Electric declines all responsibility for damages due to improper use of this product, failure to adhere to the instructions given in this manual, or repairs or changes done by those other than a technician authorized by the manufacturer.
- Sanyo Electric shall not be held responsible for any damage caused by optional devices or consumable items used with this product other than those supplied with this product or those specified by Sanyo Electric.
- Sanyo Electric shall not be held responsible for any losses or loss of revenue resulting from the loss of data caused by the malfunction, or the repairing of a malfunction, of this product.

COPYRIGHTS

This manual and the software are copyrighted materials from Sanyo Electric Co., Ltd.

PowerPC is a registered trademark of International Business Machines Corp. (USA)

Macintosh and QuickTime are registered trademarks of Apple Computer, Inc. in the USA and other countries.

Microsoft and Windows is a registered trademark of Microsoft Corporation in the USA and other countries.

DirectX is a registered trademark of Microsoft Corporation in the USA and other countries.

Intel and Pentium are registered trademarks of Intel Corporation (USA)

All other brand or product names mentioned in this manual are trademarks or registered trademarks of their respective companies.

CONTENTS

INTRODUCTION	3
About this manual	3
The software	4
Directory map	4
OPERATING ENVIRONMENT	5
Operating systems	5
MOUNTING AND DISMOUNTING YOUR DIGITAL CAMERA	7
For WINDOWS XP users	8
For WINDOWS Me and WINDOWS 2000 users	10
For WINDOWS 98/WINDOWS 98SE users	13
For MAC OS9.xx users	17
For MAC OSX users	18
INSTALLING THE APPLICATION SOFTWARE	19
Windows	20
Macintosh	22
HOW TO USE PhotoExplorer	24
Set up the environment	24
To copy image data to the computer	27
PhotoExplorer features	28
USING AS A PC CAMERA	29
Before installing	29
How to install the driver	29
ABOUT MotionDirector	31
Importing	31
Output format and playback	31

INTRODUCTION

This manual describes how to install and operate the Sanyo Software Pack. Please read this manual carefully, in order to use the images and audio recordings captured with your digital camera in a wide range of applications.

About this manual

The explanations in this manual conform to the following conventions.

- The examples given in this manual are generally based on a Windows environment. For Macintosh users, while the menu names and screen indications may be different, this is not an impediment to understanding the operation. In those places where the operations for Macintosh users and Windows users differ, specific explanations are provided.
- In this manual, the SD Memory Card and Multi Media Card used in the digital camera are both referred to as “card”.
- This manual is designed for users with the following computer skills:
 - Knowledge of basic computer operations
 - Knowledge of basic mouse operations
 - Knowledge of how to open, close, move, minimize and maximize windows
 - Knowledge of how to move from one folder to another folder

Detailed information about the operations listed above can be found in the printed or online manuals accompanying the computer or operating system software.

Symbols used in this manual

NOTE Extra information about software or cautionary notes.

CAUTION Points requiring special caution.

[page xx] Refer to the page indicated for detailed information.

The software

The following software applications are in the Sanyo Software Pack.

■ Driver software

- USB driver
The USB driver is necessary when using the USB interface in a Windows 98/Windows 98SE environment.
- PC camera device driver
Required for using PC camera with Windows XP.


■ Application software

Please see page 19 for a summary of each software program.

- QuickTime 6.5
In this manual, referred to as QuickTime.
- PhotoExplorer 8.0SE Basic (Windows)/PhotoExplorer for Mac 2.0 (Macintosh)
In this manual, referred to as PhotoExplorer.
- MotionDirector SE 1.1 (Windows)
In this manual, referred to as MotionDirector.

Directory map

Below is a directory map of the Sanyo Software Pack contents.



* The drive name may be different on your computer.

OPERATING ENVIRONMENT

Operating systems

■ Windows environment

USB storage class

A computer with a standard-equipped USB port, and preinstalled with Windows 98 or Windows 98SE is required. Correct operation cannot be guaranteed for models that have been upgraded to Windows 98 from Windows 3.1 or Windows 95.

Application software and PC Camera driver

Software	CPU	Memory	Hard disk	OS
QuickTime	Pentium or faster	128MB or more	11MB or more	Windows 98*/Me/2000/XP
Photo Explorer	Pentium II 350MHz or faster	64MB (WindowsXP: 128MB) or more	18MB or more	Windows 98*/Me/2000/XP
MotionDirector	Pentium III 1GHz or faster	256MB or more (512MB recommended)	100MB or more	Windows 98SE/Me/2000/XP
PC Camera driver	Pentium II or Celeron 300MHz or faster	128MB or more (256MB recommended)	250MB or more	Windows XP (SP1, DirectX 9.0b or later)

* Including Windows 98SE

■ Macintosh

USB storage class

A model with a standard-equipped USB port, and preinstalled with Mac OS 9.0, 9.1, 9.2, Mac OS X10.1 or later.

Application software

Software	CPU	Memory	Hard disk	OS
QuickTime*	400MHz Power PC G3 or faster	128MB or more	19MB or more	Mac OS X 10.2.5 - 10.3.x
Photo Explorer	Power PC or faster	64MB or more	20MB or more	Mac OS 9.0 (CarbonLib 1.4) or later Mac OS X 10.1 or later

* Mac OS 8.6-Mac OS 9.X, QuickTime 6.0.3

CAUTION

When using in a Mac OS X Classic environment

- It is not possible to save or load data directly to or from the card installed in the camera. The data must first be saved once to your hard disk.

MOUNTING AND DISMOUNTING YOUR DIGITAL CAMERA

The following is an explanation of how to connect your camera to a personal computer, enabling you to load the card data from your camera to the computer (mount), and also how to remove the card from a camera connected to your personal computer as well as disconnect the camera from your personal computer (dismount).

■ Cautions when mounting your digital camera as a removable disk

- Do not alter files or folders in your digital camera in any way. Doing so may result in your camera not recognizing that data.
- Do not edit files in your digital camera. If you want to edit files, first copy them to your computer's hard drive.
- Cards formatted on your computer cannot be used by your digital camera. Format all cards to be used by your digital camera with your digital camera.

For WINDOWS XP users

Mounting your digital camera

- 1 **Start your computer.**
- 2 **Connect your digital camera to the computer's USB connector, and set the camera to the card reader mode.**
 - For an explanation on how to connect the camera to your computer and how to set it to the card reader mode, refer to your camera's instruction manual.
 - The message [Found New Hardware] appears in the task tray, showing that the camera is recognized as a drive.
- 3 **Install a card in the camera.**
 - The card is recognized (mounted) as a disk, and the [Removable Disk (E:)] window opens.
 - The drive name (E:) may be different on your computer.
- 4 **Select an action.**
 - Select the desired procedure from the [Removable Disk (E:)] window.

Dismounting your camera

CAUTION

- To remove the card or disconnect your camera, be sure to follow the procedure below. Failure to follow this procedure may cause faulty operation of your computer or loss of card data.
- **Removing the card**
- ➊ **Right-click on the camera icon ([Removable Disk (E:)]) in [My Computer].**
 - A menu appears.
 - The drive name (E:) may be different on your computer.
 - ➋ **Select [Remove] from the menu.**
 - ➌ **Confirm that the camera's accessing indicator is not lit or flashing, and remove the card.**
 - For an explanation on how to remove the card from your camera, refer to your camera's instruction manual.
- **Disconnecting your digital camera**
- ➊ **Click on [Safely Remove Hardware] in the task tray, and select [Safely remove USB Mass Storage Device – Drive (E:)].**
 - You can now disconnect the camera.
 - The drive name (E:) may be different on your computer.

Mounting your digital camera

- 1 **Start your computer.**
- 2 **Connect your digital camera to the computer's USB connector, and set the camera to the card reader mode.**
 - For an explanation on how to connect the camera to your computer and how to set it to the card reader mode, refer to your camera's instruction manual.
 - The camera is recognized as a drive, and [Removable Disk (E:)] appears in the [My Computer] window.
 - The drive name (E:) may be different on your computer.
- 3 **Install a card in the camera.**
 - The card is recognized (mounted) as a disk.
 - Double-click on the [Removable Disk (E:)] icon in [My Computer], and you can process the contents of the card installed in your camera exactly like you would the data in the other computer drives.

Dismounting your camera

CAUTION

To remove the card or disconnect your camera, be sure to follow the procedure below. Failure to follow this procedure may cause faulty operation of your computer or loss of card data.

■ Removing the card

- ➊ **Right-click on the camera icon ([Removable disk (E:)] in [My Computer].**
 - A menu appears.
 - The drive name (E:) may be different on your computer.
- ➋ **Select [Remove] from the menu.**
- ➌ **Confirm that the camera's accessing indicator is not lit or flashing, and remove the card.**
 - For an explanation on how to remove the card from your camera, refer to your camera's instruction manual.

■ Disconnecting your digital camera

- ➊ Right-click on [Unplug or Eject Hardware] in the task tray.
- ➋ Select [Unplug or Eject Hardware].
 - The [Safe to Remove Hardware] dialog box will open.
- ➌ Double-click on [USB Mass Storage Device], select [SANYO VPC-J4 USB Device] from the [Stop Hardware Device] dialog box, and click on the OK button.
- ➍ Click on the OK button.
 - You can now disconnect the camera.

For WINDOWS 98/WINDOWS 98SE users

Mounting your camera

For Windows 98 and Windows 98SE users, please install the USB drivers (SANYO Digital Camera Mass Storage Drive and SANYO Digital Camera Controller). Install the SANYO Digital Camera Mass Storage Driver before installing the SANYO Digital Camera Controller.

- ❶ **Insert the CD-ROM (Sanyo Software Pack) in your computer's CD-ROM drive.**
- ❷ **Connect the digital camera to your computer, and set the digital camera to the card reader mode.**
 - For details, refer to your camera's instruction manual.
 - The [Add/Remove Hardware Wizard] dialog box will open.
 - If the [Add/Remove Hardware Wizard] dialog box does not appear, double-click on the [Add Hardware] icon in [My Computer] to open it, and proceed to step ❸.
- ❸ **Click on the [Next] button.**
- ❹ **Specify the USB driver search method and search location.**
 - ❶ Place a check in the [Search for the best driver for your device. (Recommended)] checkbox, and click on the [Next] button.
 - ❷ Place a check in the [Specify a Location] checkbox, and click the [Browse] button.
 - The [Browse for Folder] dialog box will open.

⑥ Specify the folder with the USB driver.

- The USB driver is in the CD-ROM's [Usb] folder, in the [Win98] folder.
 - ① Double-click on [Sanyodsc(D:)].
 - "(D:)" denotes the CD-ROM drive name, which may be different on your computer.
 - ② Double-click on [Usb].



- ③ Double-click on [Win98].

⑦ Click on the [OK] button.

- The [Browse for Folder] dialog box closes, and [D:\USB\WIN98] appears in the [Specify a location:] field. The first character (D) may vary depending on your computer configuration.

⑧ Click on the [Next] button.

⑨ When the dialog box appears announcing completion of the installation, click the [Finish] button.

- Installation of the SANYO Digital Camera Mass Storage Driver is now completed. After a while, the [Add/Remove Hardware Wizard] dialog box appears again. Continue to the next step to install the SANYO Digital Camera Controller.

⑩ Install the SANYO Digital Camera Controller.

- Use the same procedure as above to install the SANYO Digital Camera Controller.
- When installation of the SANYO Digital Camera Controller is completed, USB driver installation is completed.

10 Confirm that the digital camera can be mounted.

- When the USB driver has been correctly installed, the digital camera appears in the [My Computer] window as a [Removable Disk] drive. The Removable Disk drive name (E:) may be different on your computer.

NOTE

If [Removable Disk] is not found...

The USB device driver has not been installed correctly. After deleting the USB device driver once by using the procedure below, install it again.

- (1) Right-click on [My Computer], and select [Properties] from the menu.
 - The [System Properties] dialog box will open.
- (2) Click on the [Device Manager] tab.
- (3) Click on [SANYO Digital Camera], and then click on the [Delete] button.
 - If there is no [SANYO Digital Camera], click on the [Cancel] button to close the dialog box, and proceed to step (4).
- (4) Insert the CD-ROM into the drive and re-install the driver.

Disconnecting your digital camera

CAUTION

- To remove the card or disconnect your camera, be sure to follow the procedure below. Failure to follow this procedure may cause faulty operation of your computer or loss of card data.

■ Removing the card

- ① **Right-click on the camera icon ([Removable disk (E:)] in [My Computer].**
 - A menu appears.
 - The drive name (E:) may be different on your computer.
- ② **Select [Remove] from the menu.**
- ③ **Confirm that the camera's accessing indicator is not lit or flashing, and remove the card.**
 - For an explanation on how to remove the card from your camera, refer to your camera's instruction manual.

■ Disconnecting your digital camera

- ① Confirm that the camera's accessing indicator is not lit or flashing.
- ② You can now disconnect the camera.

For MAC OS9.xx users

Mounting your camera

- ① Start your computer.
- ② **Connect your digital camera to the computer's USB connector, and set the camera to the card reader mode.**
 - For an explanation on how to connect the camera to your computer and how to set it to the card reader mode, refer to your camera's instruction manual.
 - The camera is recognized as a drive and appears as an icon named [Untitled] on the Desktop.
 - Double-click on the [Untitled] icon, and you can process the contents of the card installed in your camera exactly like you would the data in the other computer drives.

Dismounting your camera

CAUTION

- To remove the card or disconnect your camera, be sure to follow the procedure below. Failure to follow this procedure may cause faulty operation of your computer or loss of card data.
- ➊ **Drag the [Untitled] icon for your digital camera on the Desktop to the trashcan.**
 - The [Untitled] icon disappears from the Desktop.
 - ➋ **Remove the card.**

For MAC OSX users

- Use the same mounting and dismounting procedure as for the MAC OS9.xx. However, if an application which automatically recognizes camera images is installed, it will be activated.

INSTALLING THE APPLICATION SOFTWARE

The Sanyo Software Pack contains the application software indicated below. Installation of each application will serve to optimize your use of the data recorded with your digital camera.

- **QuickTime***
Play back video clips. The recorded audio is played back at the same time.
 - **PhotoExplorer**
Organizing the data recorded with your digital camera is easy to understand using the graphic screen.
 - **MotionDirector**
Use MotionDirector to remove motion blur from video clips captured with your camera and to make a single panorama still shot from a video clip recorded while panning.
- * By upgrading from QuickTime to QuickTime Pro, you will be able to edit QuickTime movies, among other features. You can upgrade from Apple Computer, Inc.'s web page at <http://www.apple.com/>.

Windows

■ QuickTime installation

- ➊ **Insert the CD-ROM (Sanyo Software Pack) in your computer's CD-ROM drive.**
 - The CD-ROM window will open after a few seconds.
 - If the window does not open, double-click on the [Sanyodsc(D:)] icon in [My Computer] to open it. "(D:)" denotes the CD-ROM drive name, which may be different on your computer.
- ➋ **Open the [QuickTime] folder and double-click on the [QuickTimeFull Installer.exe] icon in the [English] folder (or whatever other language you prefer).**
 - The QuickTime setup window for beginning the installation procedure will open.
- ➌ **Follow the instructions on the screen to install the application.**
 - The installer program is preset to properly install the QuickTime software.
 - If you are unfamiliar with the computer, we recommend clicking the [Next] button at each screen.
 - Do not enter anything in the [Enter Registration] dialog box, and click on the [Next] button.
 - During the installation, the QuickTime setup screen will appear. For setup instructions, please refer to the following website:
<http://www.apple.com/>
- ➍ **Once the dialog box appears announcing completion of the installation, click on the [Close] button to close the box.**
 - This completes the installation of QuickTime.

■ PhotoExplorer/MotionDirector installation

① Insert the CD-ROM (Sanyo Software Pack) in your computer's CD-ROM drive.

- The CD-ROM window will open after a few seconds.
- If the window does not open, double-click on the [Sanyodsc(D:)] icon in the [My Computer] window to open it. "(D:)" denotes the CD-ROM drive name, which may be different on your computer.

② Begin installation.

<Installing PhotoExplorer>

- Double-click on the [Setup.exe] icon in the [PhotoExplorer] folder.

<Installing MotionDirector>

- Double-click on the [Setup.exe] icon in the [MotionDirector] folder.

③ Follow the instructions on the screen to install the application.

- During PhotoExplorer installation, the user registration screen will appear. For user registration instructions, please refer to the following website:
<http://www.ulead.com/>
- When a dialog box prompting you to restart your computer appears, restart your computer.

Macintosh

■ QuickTime installation

- ➊ **Insert the CD-ROM (Sanyo Software Pack) in your computer's CD-ROM drive.**
 - The CD-ROM window will open after a few seconds.
 - If the window does not open, double-click on the CD-ROM icon [SanyoDSC] on the Desktop.
- ➋ **Open the [QuickTime] folder.**

<Mac OS 8.6 or 9>

- ➌ **Open the [OS 8.6/9] folder and double-click on the [QuickTime Installer] icon in the [English] folder (or whatever other language you prefer).**
 - The QuickTime setup window for beginning the installation procedure will open.

<Mac OS X 10.1.5 or 10.2.3>

- ➍ **Open the [OS X v10.1.5] or [OS X v10.2.3 or later] folder.**
- ➎ **Open the [QuickTime 65.pkg] folder.**
- ➏ **Follow the instructions on the screen to install the application.**
 - The installer program is preset to properly install the QuickTime software.
 - Do not enter anything in the [Enter Registration] dialog box, and click on the [Next] button.
 - When a dialog box prompting you to restart your computer appears, restart your computer.

■ PhotoExplorer installation

❶ Insert the CD-ROM (Sanyo Software Pack) in your computer's CD-ROM drive.

- The CD-ROM window will open after a few seconds.
- If the window does not open, double-click on the CD-ROM icon [SanyoDSC] on the Desktop.

❷ Install the PhotoExplorer.

- Open the [PhotoExplorer] folder and copy the [English] folder (or whatever other language you prefer) to your hard disk.
- When the folder has been copied, installation of the application is completed.

NOTE

About the [Carbon Lib] folder

- If your computer's CarbonLib file (extension file) is earlier than version 1.4, please install the CarbonLib file (in the [Carbon Lib] folder) to the extension folder.

HOW TO USE PhotoExplorer

To copy data from your camera to your computer, when you open the drive for your camera from [My Computer], options are shown for copying data to your computer and for using PhotoExplorer to copy data. Explained in this section is how to use PhotoExplorer to copy the camera's data to your computer. For a detailed explanation of PhotoExplorer, please see the Help menu of PhotoExplorer.

Set up the environment

Specify the source of the data (data location in your camera) to be copied.

■ Setup

① Connect your camera to a computer, and set the camera to the card reader mode.

- The procedure is explained in your camera's Instruction Manual.

② Confirm the camera connection.

<Windows>

Double-click on the [My Computer] icon.

- The [Removable Disk (E:)] icon appears.
- The drive name (E:) may be different on your computer.

<Macintosh>

- An icon named [Untitled] appears on the Desktop.

■ Run PhotoExplorer

① Complete the setup.

② Run the program.

<Windows>

Double-click on the [Ulead Photo Explorer8.0 SE Basic] icon on the Desktop.

- PhotoExplorer starts, and the PhotoExplorer window opens.

<Macintosh>

Open the folder in which PhotoExplorer was installed, and double-click on the PhotoExplorer icon.

- PhotoExplorer starts, and the PhotoExplorer window opens.

■ Set the camera drive

Specify the drive of the camera connected to the computer. Once set, the drive is retained until you change it.

❶ Run PhotoExplorer (see page 24).

❷ Click on the camera icon on the Toolbar.

- The [Digital Camera Wizard] dialog box will open.

④ Specify the camera drive.

<Windows>

- ① Click on the drive name (A:\) to the right of [Camera Drive and Card Reader].
 - The [Select Image Source] dialog box will open.
- ② Turn ON the [Load Directly from Camera Memory Card or Disk] option button, and in the [Location] list box select the camera drive → [DCIM] → [100SANPH] folder.
- ③ Click on the [OK] button.
 - The [Digital Camera Wizard] dialog box will open.
 - The drive name to the right of [Camera Drive and Card Reader] changes to the specified drive name.

<Macintosh>

- ① Click on the [Camera Flash Drive] column icon.
 - The [Select Removable Drive] dialog box will open.
- ② Click on the drive (untitled) for the camera connected to your computer, and click on the [Select] button.
 - The [Camera Flash Drive] column drive name becomes [untitled].
- ③ Check the [Create Subfolder] checkbox.

To copy image data to the computer

- Perform the procedure to “Copy data” below through step ②.

For setup only

- If you click on the [Cancel] button, the [Camera Wizard] window will close.

Copying data

Copy image files to the computer from the card installed in your camera.

① **Connect your camera to the computer, and set the camera to the card reader mode.**

- PhotoExplorer starts.
- Instructions for connecting your camera to a computer can be found in your camera's Instruction Manual.

If PhotoExplorer does not start...

- ① Run PhotoExplorer (see page 24).
- ② The [Digital Camera Wizard] dialog box will open.

② **Click on the [Start] button.**

- Copying begins.
- A folder with the name as indicated below is automatically created, to which the data is copied.
Windows: C:\My Documents\SANYO_PEX
Macintosh: Macintosh HD:Ulead Photo Explorer
- When copying is completed, the [Done] dialog box will appear.

③ **When copying is completed, click on the [OK] button.**

- The copied data is shown in a thumbnail window.

PhotoExplorer features

Import digital data, manage blocks of files, search files

With the PhotoExplorer you have visually integrated control over multiple files, from digital camera images to DV camcorder video files to audio files (such as MP3 and WAV files).

■ Manage and edit image files

Viewing images

Images can be viewed full-size or full-screen. Use the keyboard controls or toolbar buttons to select the menu, and you can browse the images or play them back, for example, in a slideshow.

Organizing and editing images

You can copy and erase image files, as well as change the file names. In addition, you can rotate and flip images, and save the edited images as new files.

Adjusting images

You can easily enhance images by clipping and adjusting the contrast, brightness, color balance, etc. The created images can be used for wallpaper or screen savers.

■ Abundant slideshow features

Slideshows containing combinations of still images and video clips can be played back. The slideshow feature comes with a large variety of image-to-image transition effects.

■ Convert the format of video clip data

Video clips (QuickTime format) that were shot with your digital camera can be converted to other formats, such as AVI and MPEG.

■ For questions about PhotoExplorer

Further information about PhotoExplorer can be found at <http://www.ulead.com/>

<Where to find the serial number>

- From the PhotoExplorer [Help] menu, select "About PhotoExplorer." The program version as well as the serial number are shown.

USING AS A PC CAMERA

If running Windows XP, you can use the VPC-J4EX/VPC-J4 as a PC camera. Before using the VPC-J4EX/VPC-J4 as a PC camera, please install the device driver.

Before installing

Before installing the PC CAMERA driver, the following upgrades should be completed.

The PC CAMERA driver cannot be installed until the following procedures have been completed.

- Upgrade Windows XP to SP1.
Install Windows XP SP1.
- Install Windows Messenger 5.0
- DirectX 9.0b End-User Runtime must be installed.
Download the DirectX 9.0b End-User Runtime and install it.
- Further details concerning upgrades can be found on the following web page: http://www.sanyo-dsc.com/dsc/support_f.html

How to install the driver

- ➊ **Insert the CD-ROM (Sanyo Software Pack) in your computer's CD-ROM drive.**
- ➋ **In the [PC CAMERA] folder, double-click on the [Install] icon in the [WinXP] folder.**
 - The dialog box to confirm the installation appears.
- ➌ **Click on the "YES" button.**
 - Installation begins.
 - If an error message appears during the installation, confirm the message contents and restart the installation procedure.
- ➍ **Restart your computer.**
 - Please reboot your computer.
- ➎ **Connect the digital camera to your computer, and set the digital camera to the PC camera mode.**
 - For details, refer to your camera's instruction manual.
 - The [Found New Hardware Wizard] dialog box will open.

NOTE

If the [USB Video Device] icon does not appear in the [My Computer] window...

- The device driver installation may not have been successful. Open the [Printer and Other Hardware] folder in [Control Panel], delete [USB Video Device] from [Scanners and Cameras], and reinstall the device driver.

ABOUT MotionDirector

Use MotionDirector to remove motion blur from video clips captured with your camera and to make a single panorama still shot from a video clip recorded while panning.

An outline of MotionDirector is introduced below. For details, please refer to online help for MotionDirector.

Importing

MotionDirector can read either of these file formats:

- MOV
- MP4

The compression coding for each is as follows:

Format	Video coding	Audio coding
MOVE	Motion JPEG	WAVE
MP4	ISO MPEG-4	AAC

The frame size is VGA (640 × 480 pixels) or less.

Output format and playback

MotionDirector can write files in the following formats:

Motion-blur correction: MPEG-4, MOV

Panorama composite: JPEG, BMP, TIFF, QuickTime VR

VR spatiotemporal images saved in the QuickTime VR format using Apple's QuickTime Player can be viewed.

SANYO

SANYO Electric Co., Ltd.