


SANYO

Operating Instructions

Electronic Rice Cooker / Steamer
ECJ-AU18




Before operating this unit, please read instructions completely.

IMPORTANT SAFEGUARDS


When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not touch hot surfaces.
3. To protect against electrical shock do not immerse cord or plug in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments is not recommended by the appliance manufacturer as they may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Do not use appliance for other than intended use.
13. Save these instructions.


PARTS IDENTIFICATION



Accessories



Rice Scoop




Scoop holder



Measuring cup
(180c.c.)


HOW TO USE (RICE)

1. Measure rice with included measuring cup.



- Wash rice in another bowl until water is relatively clear.


2. Put washed rice in pan. Add water.



e.g. For 6 cups of rice, add water to LEVEL INDICATOR 6.


- Adjust water quantity to your personal taste.
- Do not cook more than MAXIMUM LEVEL.

3. Set pan in cooker.




- Wipe outside of pan before use. A wet pan may cause a cracking noise while cooking, and may damage unit.

4. Close outer lid until it clicks.




- If outer lid is not closed securely, cooking will be affected.

5. Attach AC cord to cooker and plug in. Immediately press switch. "Rice Cook" lamp tells you cooking has started.




6. When rice is done, the switch will pop up. "Keep Warm" lamp lights to signal "Keep Warm" function.



- Do not plug in until ready to cook. Otherwise, rice may be ruined.

- After the switch pops up, leave covered for at least 15 minutes to steam rice.

7. Scoop and mix rice well.




- "Keep Warm" function continues until unplugged.

HOW TO USE (STEAM PLATE)

1. Put the steam plate into inner pot with rim facing downwards.
2. Add adequate water but do not exceed the level of the steam plate.
3. Put the food on the steam plate then switch on the unit.

HOW TO USE (PORRIDGE)


- Put washed rice in porridge pan.
 - Measure the rice according to the correct table for the desired Porridge.
 - The washing of rice is the same as stated in the rice cooking section.



- Add water
 - Add water to the level as per the scale on the porridge pan.


Rice	1 cup	2 cups	3 cups
Porridge	4 bowlfuls	8 bowlfuls	12 bowlfuls

- For an example, add water to level indicator "1" for one cup of rice.




- After adding 180 c.c. of water into the pan, put it into the body.
 - Add one cup of water.
 - The water must be added for cooking.

- Put the Porridge pan with the rice and water added into the pan.
 - Close the outer lid, which should be tight.



- Turn on the switch.
 - Plug in the AC cord, the "Keep Warm" lamp is on.
 - Press the switch, the "porridge cook" lamp will turn on.



- Automatic keep warm function for porridge cooking.
 - Refer to the table on the right for the required cooking time. (provided for reference only)
 - Time will vary according to the temperature of air and water.


- Open the outer lid and stir the porridge, then it is ready to serve.
 - Please stir the cooked gruel to make it even and delicious.

Rice	1 cup	2 cups	3 cups
Time	Approx. 25min	Approx. 30min	Approx. 35min

PRECAUTIONS

1.If pan is not in cooker, cooking will not begin.

2.Always keep pan bottom and heater clean and dry. Any foreign matter between them will cause cooker to malfunction.




3.The switch cannot be engaged when pan is not in body nor right after cooking. Do not depress by force.




4.Using "Keep warm" function for more than 12 hours may cause discoloration or an objectionable odour in the rice.

5.Set unit on a stable surface. Do not expose to water, high humidity or heat sources.




6.Do not cover outer lid when in use.

7.Do not use pan directly on open flame.



8.Do not immerse in water.



HOW TO CLEAN

Unplug before cleaning.

1. Remove the inner lid, then soak pan and inner lid in hot water and wash with a sponge.
2. Wipe the body with a damp cloth. Do not immerse in water.
3. Dew collector and scoop holder should be removed and cleaned.
 - Do not use abrasive cleaners or steel wool. Clean with non-metal brush or sponge.


Non-Stick coated pan

- Use a sponge to clean.
- Use a plastic or wooden rice scoop, not metal utensils which may damage pan surface.
- Non-stick coating may discolour after long use, due to water and steam. This won't affect non-stick or sanitary properties.

HOW TO LOAD AND UNLOAD


1. Dew collector

To remove, hold sides and pull out.
To attach, reverse directions.




2. Scoop holder

Remove in the direction of the arrow.



3. Inner lid

To attach inner lid press onto shaft.



SPECIFICATIONS

Model	ECJ-AU18
Power Supply	240V 50Hz
Capacity	0.54 ~ 1.8ℓ
Thermal fuse	188°C
Dimensions(HXWXD)	28(cm)x28(cm)x27.5(cm)
Weight	4.2kg
Porridge	Complete