




**SANYO**

**RM 6000AS**





# **SANYO FM/AM ELECTRONIC DIGITAL CLOCK RADIO**

## **OPERATING INSTRUCTIONS**

For maximum usage, please read the following instruction manual carefully before operating the unit.

## HELPFUL HINTS

1. Keep the radio away from heating appliances and electrical noise-generating devices such as fluorescent lamps and motors.
2. The radio should not be directly exposed to sunlight, and should be kept free from dust, moisture and vibration.
3. To keep the cabinet clean, wipe off dust and stains with a soft damp cloth. **DO NOT USE A SOLUTION CONTAINING BENZOL OR PETROLEUM PRODUCTS.**



## GENERAL OPERATING

1. Stretch the AC power cord to its full length to ensure best FM reception and connect it to a 240 volt AC, 50 Hz outlet.
2. This electronic digital clock radio is equipped with two TIME SET buttons for accurate easy time setting.

- A. FAST button for hourly AM or PM time setting.
  - B. SLOW button for to the minute time setting.
- NOTES: \* Since this is a 24-hour electronic digital clock, the proper AM or PM time setting must be made.
- \* When depressing the DIMMER button, the timer digits will be dimmed.

## HOW TO SET TIME

- Step 1. FAST button: Push this button until the digital clock is set within 20 – 30 minutes before the desired AM or PM time.
- Step 2. SLOW button: Push this button to set the time within desired minute.

## RADIO OPERATION

- 1. To turn the radio on: Slide the AUTO/ON/OFF switch to the ON Position.
- 2. Use the FM/AM switch to select the desired broadcast band. AM for AM broadcast and FM for FM broadcast.

AM 510 – 1605 kHz

FM 87,5 – 108 MHz

- 3. Turn the TUNING knob to obtain desired station.
- 4. Adjust the VOLUME control knob to desired sound level.
- 5. Set the TONE control switch for desired sound quality, to HIGH for treble and LOW for less treble.
- 6. To turn the radio off: Slide the AUTO/ON/OFF switch to the OFF Position.

## AERIAL (ANTENNA)

This radio is equipped with a built-in ferrite bar aerial for AM reception. Since this aerial is directional, it may be helpful to turn the radio a few degrees to the left or right to get better reception in fringe areas. For FM reception, a short wire aerial is provided, rewind the short wire aerial and extend it to full length

## SLEEP TIMER

The radio can be adjusted to play and then turn off automatically after a predetermined interval of up to 59 minutes.

- Step 1. Be sure the AUTO/ON/OFF switch is in the AUTO or OFF position.
- Step 2. Press the SLEEP timer button halfway down or until only the last two digits appear.

- Step 3. The minutes indicated may be decreased by fully pressing down the SLEEP timer button.  
For example, 00, 59, 58, 57,..... 03, 02, 01, 00, 59, 58, 57,.....  
When minutes appear the desired sleep timer period, release the sleep button.
- Step 4. The SLEEP timer is now set and normal time will appear on the clock.
- Step 5. If you want to turn off the radio immediately, touch the AUTO REPEAT/SLEEP OFF button.

## MUSICAL OR BUZZER WAKE-UP ALARM

1. A. Set the RADIO/BUZZER switch to RADIO Position, if you wish to be awoken by the radio.  
B. For buzzer awaking, set the RADIO/BUZZER switch to the BUZZER Position. Delete following items 2 & 3, and continue with item 4. The radio or buzzer will start to operate at the preset time.
2. Slide the AUTO/ON/OFF switch to the ON Position to turn the radio on and set the FM/AM switch to FM or AM position.
3. Preset the TUNING knob of the radio to the desired station and adjust the VOLUME and TONE controls to the desired sound level and tone quality.  
quality.
4. Move the AUTO/ON/OFF switch to the AUTO Position to switch the radio off, and turn on "wake-up" mode.
5. Press the TIME-ALARM button, the button is locked and then set the desired "wake-up" time by using the TIME SET (FAST and SLOW) buttons. After you have set desired "wake-up" time, repress the TIME-ALARM button for actual time.
6. To stop the radio or buzzer: Press the ALARM-OFF button. Or if you want to continue to listen to the radio, slide the AUTO/ON/OFF switch to the ON Position.

- NOTES: \*
- \* Since this digital electronic clock radio has 24-hour memory, you must check AM/PM indicator while setting desired actual or "wake-up" time.
  - \* The radio will play for about one hour after selected "wake-up" time and then turn off automatically.
7. Snooze mode: The radio can be regulated to waken you gently up to 5 nine minute snooze radio/buzzer alarm cycles, thus permitting you to snooze 5 times between alarms.

- A. To stop the radio or buzzer, touch the AUTO REPEAT/SLEEP OFF button.
- B. You may safely doze off with the knowledge that you will be awakened again nine minutes later.
- C. To cancel snooze mode: Press the ALARM OFF button down fully and then release.

### **COMBINATION SLEEP TIMER AND MUSICAL OR BUZZER WAKE-UP**

Your radio can be adjusted to turn off automatically after a preset interval up to 59 minutes, and then turn on again at wake-up time.

1. Slide the AUTO/ON/OFF switch to the AUTO Position.
2. Set the SLEEP timer to any period between "01" and "59" minutes as previously described in sleep timer section.
3. Turn the TUNING knob to select the desired station and adjust the VOLUME and TONE controls to the desired sound level and tone quality.
4. Set the "Wake-up" time according to instructions in "MUSICAL OR BUZZER WAKE-UP ALARM" section previously described.

### **EARPHONE SOCKET**

For private listening, connect an 8 ohm earphone (optional) to the earphone socket. The internal speaker is automatically disconnected when an earphone is plugged in.

**SANYO ELECTRIC CO., LTD.**  
**SANYO ELECTRIC TRADING CO., LTD.**  
OSAKA, JAPAN